

	PAGE		PAGE
Adapter, 102D.....	80	Loudspeakers, 750A and 751B.....	60
Adapter, 712A.....	12	Loudspeakers, 753B and 753C.....	61
Adapter, 713A.....	13	Master Control Room Switching Systems.....	27
Amplifier, 106A Line.....	35	Meter, KS-8207.....	58
Amplifier, 116B Pre.....	43	Meter, KS-8208.....	58
Amplifier, 120C Pre-Mixing.....	37	Meter, KS-8218-1.....	58
Amplifier, 121A Line.....	38	Meter, KS-10003.....	71
Amplifiers, 124 Series Loudspeaker and General Purpose.....	39	Meter Cabinet, KS-10065.....	58
Amplifiers, 124A and 124E Monitor and Audition.....	40	Microphone, 633A Dynamic.....	6
Amplifier, 124F Monitor and Talkback.....	42	Microphones, 639A and 639B Cardioid.....	3
Amplifier, 124G Monitor and Audition.....	44	Microphone, 640AA Condenser.....	7
Amplifier, 129A Pre-Mixing.....	46	Mounting Plates, 177A and 177B.....	76
Amplifier, 130B Twin Channel Main.....	48	Mounting Plates, 190A and 190B.....	76
Amplifier, 131A Monitor.....	50	Mounting Plates, 993A, 993B and 993C.....	76
Amplifier, 132A Main.....	52	Mounting Plates, Relay.....	80
Amplifier, 132B.....	53	Mounting Plates, U and Y Type.....	80
Amplifier, 133A Line.....	54	Panels, Blank.....	75
Amplifier, RA-1095.....	10	Panel, 260A Telephone.....	67
Amplifier, 1126C Program Operated Level Governing.....	33	Panel, 268A Order Wire.....	67
Apparatus Blanks, 32B and 39B.....	82	Panel, 270B Output Switching.....	68
Auto Transformers, 18A and 19A.....	74	Panel, 271B Output Switching.....	68
Cable, Lead Covered.....	88	Panel, 272A Program Line.....	69
Cable Terminal Box, Type GA26.....	79	Panel, 279A Equalizer.....	69
Cables, Type "BUA" Lead Covered.....	89	Panel, 288A Terminal.....	79
Cables, Type "OUA" Lead Covered.....	88	Panels, 296 Type.....	75
Connecting Blocks, 11 and 31 Type.....	79	Plugs, 47A and 47B.....	87
Consoles, Custom Built.....	19	Plugs, 241A and 241B.....	87
Console, 40A.....	23	Plug, 311A.....	12
Cord Assembly for Microphones.....	12	Power Unit, 12A.....	23, 65
Cords, P2A and P2AA.....	71	Rectifiers, 18A and 18B.....	63
Cord, P3J.....	71	Rectifier, 20B.....	64
Cordage, KS-7133.....	13	Rectifier, KS-5653 List 3.....	66
Designation Strips, 90A Type.....	81	Rectifier, KS-7593.....	65
Distributing Frames, 1425 Type.....	77	Relays, U and Y Type.....	80
Equalizer, 23A.....	70	Repeating Coils, 111C and 119C.....	71
Equalizer, KS-13386.....	16	Repeating Coil, 153A.....	72
Fanning Strips, 15 Type.....	77	Repeating Coil, 154C.....	73
Floor Stand Weights.....	13	Repeating Coil, 170B.....	73
Hand Telephone Set, F2B-3 Type.....	71	Repeating Coil, 171A.....	16
Headset D-97690.....	70	Repeating Coil, 172A.....	73
Headsets, 1002F and 1002H.....	70	Repeating Coil, 177C.....	74
Jacks, 218A and 218J.....	81	Reproducer, 9 Type.....	15
Jack, 225CE.....	81	Reproducer Arm, 5A.....	16
Jack, 410D.....	81	Reproducer Group, 109 Type.....	15
Jack, 442A.....	12	Resistances, 18 and 19 Type.....	82
Jack Mounting, 221A and 222A.....	81	Speech Input Console, Custom-Built.....	19
Junction Boxes, 7A and 7B.....	24	Speech Input Consoles, 22D.....	31
Key, 92 Type.....	84	Speech Input Equipment, 23C.....	28
Key, 479.....	83	Speech Input Equipment, 25B.....	22
Key, 498A.....	84	Supporting Brackets, 711A and 712A.....	16
Keys, 547A and 547B.....	85	Table, KS-10284.....	23
Keys, 552A, 553A and 554A.....	85	Terminal Strips, 700A.....	78
Key Handle, KS-10011.....	86	Transmitter Attachment, 8B (Baffle).....	14
Key Units, 2 Type.....	86	Transmitter Attachment, 9A (Swivel Joint).....	13
Knobs, KS-10088 and KS-10283.....	86	Transmitter Attachment, 11A, (Suspension Mounting).....	13
Lamps, 2 Type.....	87	Transmitter Mountings, 22A, 23A and 24A.....	13, 14
Lamp Caps, 2 Type.....	87	Volume Indicators, 754A and 754B.....	57, 58
Lamp Caps, 72 Type.....	88	Wire, J1.....	88
Lamp Sockets, 47B and 49B.....	87	Wire, KS-13385.....	88
Loudspeaker, 728B.....	59	Wire, P2.....	88

## NUMERICAL INDEX

	PAGE		PAGE
J1 Wire.....	88	170B Repeating Coil.....	73
2 Type Keys.....	86	171A Repeating Coil.....	16
2 Type Lamps.....	87	172A Repeating Coil.....	73
2 Type Lamp Caps.....	87	177A and 177B Mounting Plates.....	76
P2 Wire.....	88	177C Repeating Coil.....	74
P2A and P2AA Cords.....	71	190A and 190B Mounting Plates.....	76
F2B-3 Type Hand Telephone Set.....	71	218A and 218J Jacks.....	81
P3J Cord.....	71	221A and 222A Jack Mounting.....	81
5A Reproducer Arm.....	16	225CE Jack.....	81
7A and 7B Junction Boxes.....	24	241A and 241B Plugs.....	87
8B Transmitter Attachment (Baffle).....	14	260A Telephone Panel.....	67
9 Type Reproducer.....	15	268A Order Wire Panel.....	67
9A Transmitter Attachment (Swivel Joint).....	13	270B Output Switching Panel.....	68
11 and 31 Type Connecting Blocks.....	79	271B Output Switching Panel.....	68
11A Transmitter Attachment (Suspension Mounting).....	13	272A Program Line Panel.....	69
12A Power Unit.....	23, 65	279A Equalizer Panel.....	69
15 Type Fanning Strips.....	77	288A Terminal Panel.....	79
18 Type Resistances.....	82	296 Type Panels.....	75
18A and 18B Rectifiers.....	63	311A Plug.....	12
18A and 19A Auto Transformers.....	74	410D Jack.....	81
19 Type Resistances.....	82	442A Jack.....	12
20B Rectifier.....	64	479 Key.....	83
22A Transmitter Mounting.....	13	498A Key.....	84
22D Speech Input Equipment.....	31	547A and 547B Keys.....	85
23A Equalizer.....	70	552A, 553A and 554A Keys.....	85
23A Transmitter Mounting.....	14	633A Dynamic Microphone.....	6
23C Speech Input Equipment.....	28	639A and 639B Cardioid Microphones.....	3
24A Transmitter Mounting.....	14	640AA Condenser Microphone.....	7
25-B Speech Input Equipment.....	22	700A Terminal Strips.....	78
GA26 Type Cable Terminal Box.....	79	711A Supporting Bracket.....	16
32B and 39B Apparatus Blanks.....	82	712A Adapter.....	12
40A Console.....	23	712A Supporting Bracket.....	16
47A and 47B Plugs.....	87	713A Adapter.....	13
47B and 49B Lamp Sockets.....	87	728B Loudspeaker.....	59
72 Type Lamp Caps.....	88	750A and 751B Loudspeakers.....	60
90A Type Designation Strips.....	81	753B and 753C Loudspeakers.....	61
92 Type Key.....	84	754A and 754B Volume Indicators.....	57
102D Adapter.....	80	993A, 993B and 993C Mounting Plates.....	76
106A Line Amplifier.....	35	1002F and 1002H Headsets.....	70
109 Type Reproducer Group.....	15	RA-1095 Amplifier.....	10
111C and 119C Repeating Coils.....	71	1126C Program Operated Level Governing Amplifier.....	33
116B Pre-Amplifier.....	43	1425 Type Distributing Frames.....	77
120C Pre-Mixing Amplifier.....	37	KS-5653 List 3 Rectifier.....	66
121A Line Amplifier.....	38	KS-7133 Cordage.....	13
124 Series Loudspeaker and General Purpose Amplifiers.....	39	KS-7593 Rectifier.....	65
124A and 124E Monitor and Audition Amplifiers.....	40	KS-8207 and KS-8208 Meters.....	58
124F Monitor and Talkback Amplifier.....	42	KS-8218-1 Meter.....	58
124G Monitor and Audition Amplifier.....	44	KS-10003 Meter.....	71
129A Pre-Mixing Amplifier.....	46	KS-10011 Key Handle.....	86
130B Twin Channel Main Amplifier.....	48	KS-10065 Meter Cabinet.....	58
131A Monitor Amplifier.....	50	KS-10088 Knob.....	86
132A Main Amplifier.....	52	KS-10283 Knob.....	86
132B Amplifier.....	53	KS-10284 Table.....	23
133A Line Amplifier.....	54	KS-13385 Wire.....	88
153A Repeating Coil.....	72	KS-13386 Equalizer.....	16
154C Repeating Coil.....	73	D-97690 Headset.....	70

*Western Electric*

